



MULTIPOINT FUEL INJECTION (MFI) CIRCUIT DIAGRAM ST3358M

- | | |
|--|---------------------------------------|
| EF1 Idle air control valve (IACV) | EF15 Tune resistor connector |
| EF2 Mass air flow sensor (MAFS) | EF16 Data link connector (DLC) |
| EF3 Engine coolant temperature sensor (ECTS) | EF17 Fuel injectors |
| EF4 Engine fuel temperature sensor (EFTS) | EF18 Fan control timer |
| EF5 Throttle position sensor (TPS) | EF19 Resistor (manual transmission) |
| EF6 Main relay module | EF20 Onboard diagnostic module (OBDM) |
| EF7 Canister purge valve (CANPV) | EM1 Service reminder indicator unit |
| EF8 Fuel pump relay module | EM2 Vehicle speed sensor (VSS) |
| EF9 Inertia fuel shut-off switch (IFS) | EM3 Service reminder light (SRI) |
| EF10 Fuel pump (FP) | IB1 Instrument binnacle |
| EF12 Malfunction indicator lamp (MIL) | IG5 Ignition coil |
| EF13 Heated oxygen sensor (HO2S) | ST2 Terminal post starter solenoid |
| EF14 Heated oxygen sensor (HO2S) | ST5 Starter/ignitionswitch |
| | AC24 Air conditioning connections |
| | F20 20 amp fuse, dash fuse box |
| | F3 15 amp fuse, dash fuse box |